

ASBESTOS ENCAPSULATION

PRODUCTS YOU'LL NEED



Agent Blue

Available in a variety of concentrates to suit your application.

[SHOP NOW](#)



Hypastat

Available in 5L and 20L containers
Hypastat is a DG product.

[SHOP NOW](#)



Peel & Stick Tape

Cotton Reinforcing Tapes are also available.

[SHOP NOW](#)



Kemseal WBE

Available in 1L, 4L, 8L and 20L containers.

[SHOP NOW](#)



Kemseal S-80

Available in 2L, 4L or 15L containers.

[SHOP NOW](#)

APPLICATION

✓ Spray **Agent Blue Moss & Mould Kill** on the asbestos area. Leave the roof for 3 months while that product works away over that time.

✓ Spray on **Hypastat** using a hand sprayer with a coarse wetting nozzle, and leave on for at least 30 mins.

Coverage:

- Mix at a ratio of 1:2 with water. i.e. 20L Hypastat is mixed with 40L water, so will make 60L. Coverage 240m².
- Once mixed this will cover approx. 4 sq metres per litre.

✓ Rinse off with a water blaster and ensure you have a clean, dry surface before continuing.

✓ Bridge sealing edges, laps, vents & joints in the roof with **Kemseal Reinforcing Tape** or **Kemseal Peel & Stick Tape**.

✓ Stir up both the **Kemseal WBE** Part A and Part B individually for a couple of minutes, until each of them is thoroughly mixed.

Continued on next page...

ASBESTOS ENCAPSULATION

APPLICATION CONTINUED

- ✓ Mix together the **Kemseal WBE** Part A and the **Kemseal WBE** Part B until well combined.
- ✓ Apply 1 Layer of **Kemseal WBE** to the whole area. Leave it to dry for approx. 1 hour, or until dry to touch.

Coverage:

- 1L Part A & Part B mixed does 6 - 8m².
- Apply the **Kemseal S-80** on top of this primer within 2 days at the latest, to ensure the primer doesn't get too hard.

- ✓ Apply the first Layer of **Kemseal S-80** using a brush or roller. Leave it to dry for approx. 3-12 hours depending on weather conditions.

Coverage:

- Apply a minimum thickness of 1L per 2m².
- A 15L bucket will coat 30m² total.
- Wait until the first coat can be walked on without causing damage before applying the second coat.

- ✓ Apply the second Layer of **Kemseal S-80** after the first coat is dry.

APPLICATION TIPS & TRICKS



To download the **SDS & Data Sheets** for these products please visit www.stratacote.co.nz/sds-and-data-sheets/

The information above is the best available Stratacote Ltd and its affiliated companies relating to our products and the use of our products. It is based on tests believed to be reliable. Stratacote Ltd assumes no liability for any damages incurred in association with the use of Agent Blue Moss & Mould Kill, Hypastat, Kemseal WBE or Kemseal S-80. Information is subject to change without notice.