

WATERPROOFING GUTTERS

PRODUCTS YOU'LL NEED



Peel & Stick Tape

Cotton Reinforcing Tapes are also available.

SHOP NOW



Kemseal WBE

Available in 1L, 4L, 8L and 20L containers.

SHOP NOW



Kemseal S-80

Available in 2L, 4L or 15L containers.

SHOP NOW

APPLICATION

- ✓ Rinse off guttering with a water blaster and ensure you have a clean, dry surface before starting.
- ✓ Bridge sealing edges, laps, vents & joints in the roof with **Kemseal Reinforcing Tape** or **Kemseal Peel & Stick Tape**.
- ✓ Stir up both the Kemseal WBE Part A and Part B individually for a couple of minutes, until each of them is thoroughly mixed.
- ✓ Mix together the Kemseal WBE Part A and the Kemseal WBE Part B until well combined.
- ✓ Apply 1 Layer of Kemseal WBE to the whole area. Leave it to dry for approx. 1 hour, or until dry to touch.

Coverage:

- 1L Part A & Part B mixed does 6 8m2.
- Apply the Kemseal S-80 on top of this primer within 2 days at the latest, to ensure the primer doesn't get too hard.
- ✓ Apply the first Layer of Kemseal S-80 using a brush or roller. Leave it to dry for approx. 3-12 hours depending on weather conditions.

Coverage:

- Apply a minimum thickness of 1L per 2m2.
- A 15L bucket will coat 30m2 total.
- Wait until the first coat can be walked on without causing damage before applying the second coat.
- ✓ Apply the second Layer of Kemseal S-80 after the first coat is dry.

To download the SDS & Data Sheets for these products please visit www.stratacote.co.nz/sds-and-data-sheets/

The information above is the best available to Stratacote Ltd and its affiliated companies relating to our products and the use of our products. It is based on tests believed to be reliable. Stratacote Ltd assumes no liability for any damages incurred in association with the use of the Kemseal WBE or Kemseal S-80. Information is subject to change without notice.